

SIGMA

Compatibility of the SIGMA TELE CONVERTER TC-1411 / TC-2011

* Dedicated tele converters for use with only those SIGMA GLOBAL VISION lenses listed in the above chart and cannot be used with any other lenses.

Please refer to the column indicating your lens mount	L-Mount	
	1.4X	2X
SIGMA 105mm F2.8 DG DN MACRO Art [A020]	AF	AF
SIGMA 60-600mm F4.5-6.3 DG DN OS Sports [S023]	AF	AF
SIGMA 100-400mm F5-6.3 DG DN OS Contemporary [C020]	AF	AF
SIGMA 150-600mm F5-6.3 DG DN OS Sports [S021]	AF	AF

- Cannot be attached to a camera and lens whose mount is different.
- Cannot be used in combination with another SIGMA TELE CONVERTER or other manufacturer's converter. Only one tele converter can be used at one time.

Note

Please attach the TELE CONVERTER to the master lens first then attach the combined TELE CONVERTER and lens to the camera body. Attaching to SIGMA TELE CONVERTER to the camera body first may cause a malfunction and accurate operation is not guaranteed.

About exposure

Using the SIGMA TELE CONVERTER decreases the effective aperture by one F-stop (with 1.4x Tele Converter) or by two F-stops (with 2x Tele Converter). Although the exposure becomes lower, the operation is optimized.